

CLEANING AND DISINFECTING AGENTS

Manufacturers	DIVERSEY	ANIOS2	DÜRR DENTAL	ECOLAB	ECOLAB2	AC Marca	SCHULKE & MAYR GmbH	SCHULKE & MAYR GmbH3		
cleaning products / Griffine range	Divosan ETHA Plus	ANIOS Surfanios Premium	Dürr FD 366	Klercide Sporidical Active Chloride	Incidin Oxywipe	Sanytol Multi-purpose 94% plant-based	Antifect Extra	Microzid sensitive wipes	Soapy water	Alcohol 50*
ABAKA	✓	✗	✓	✗	✗	●	✓	✓	✓	✓
BOEING 2000	✗	✓	✓	✓	✓	✓	✓	✓	✓	✓
COMETE	✗	✗	✗	✗	✗	✗	✓	✗	✓	✗
DIABOLO CHICK	✗	✓	✓	✓	✗	✗	✓	✓	✓	✓
DIABOLO CLUB	✗	✓	✗	●	✗	✓	●	✓	✓	✓
ELFORM / DENFORM	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
ESPRIT	✓	✗	✓	✗	✗	●	✓	✓	✓	✓
ESPRIT DOTTY	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
ESPRIT DREAM	✓	✗	✓	✗	✗	●	✓	✓	✓	✓
FLANEL	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
GINKGO	✗	✗	●	✓	✗	✗	✗	✗	✓	✓
GLOBE	✗	✓	✓	✓	✓	✓	✓	✓	✓	✓
KALYTERA	✓	✓	✓	✗	✗	✗	✓	✓	✓	✓
MEDISTAT	✗	✗	●	●	●	✗	✗	✗	✓	✗
MUNDIAL	✗	✓	✓	✓	✓	✓	✓	✓	✓	✗
NEPTUNE	✗	✓	✓	✓	✓	✓	✓	✓	✓	✗
PONANT	✗	✓	✓	✓	✓	✓	✓	✓	✓	✗
URBAN	✓	✗	●	✗	●	✗	✓	●	✓	✓

	The table above shows the recommended, conditional, and non-recommended cleaners/disinfectants for the maintenance of Griffine coated fabrics.									
Recommendations	✓	Recommended for the maintenance of Griffine coated fabrics under the conditions indicated by the supplier.								
	●	Can be used under certain conditions: must not be kept in prolonged contact with our coatings, must be rinsed with water after application.								
	✗	Not recommended for the care of Griffine coated fabrics.								
Test Protocol	The product is applied in the highest concentrations indicated by the supplier. Frequency: Every 30 minutes 10 times a day for 30 consecutive days. A rinse with water is carried out at the end of each day									
Notes	Griffine cannot be held responsible for changes in the formulation of Cleaners/Disinfectants products at the initiative of the manufacturers.									

